

REINFORCING BARS EMBEDDED IN CONCRETE “UFER Ground”

2023 National Electrical Code (NEC) 250.50 & MRC 2015

Q: Do we have to install re-bar in the concrete footing to ground the Electrical Service?

A: No, unless it is in the Specs or if the Builder, Owner or Electrician want it installed. (a)

Q: If we do install steel re-bar, does it need to be Grounded to the Electrical Service?

A: Yes, if it at least 20' long and embedded in the concrete footing or wall. (b) (c)**

Electrical Services are typically Grounded with two 8' Ground Rods that are driven into the ground near the electric service and are at least 6' apart per NEC 2023 and MRC 2015. If a Ufer Ground is used then ground rods are not needed (per electrical code).

NEC 250.50 **requires** bonding the grounding electrode system to reinforcing bars that are embedded in concrete footings and/or concrete foundation walls. **(a)**The NEC (MRC 2015) does not require reinforcing bars to be installed in concrete if they are not needed per the approved building plans. **(b)**If steel reinforcing bars **are** used at combined lengths of at least 20' in a footing or wall, they **must** be bonded to the electrical service. Only *one* section (area) of reinforcing bar(s) needs to be bonded if several areas of re-bar are used in the building. This requirement typically applies to re-bar that is installed in footings and foundations in direct contact with the ground. **(c)**Reinforcing bars installed in foundation walls that are **insulated or waterproofed** on the exterior and are not backfilled on the interior do **not** require bonding as the wall is considered not in direct contact with the earth.

NEC 250.52(3) describes a “Concrete-Encased Electrode (Ufer Ground)” as a minimum of a 20' x ½” or larger re-bar embedded in at least 2” of concrete on all sides. At least a 20' length embedded in concrete that is in direct contact with the earth; such as a footing. *Note: a 20' re-bar bent up 6” out of a footing no longer has 20' embedded in the concrete footing.* Re-bars may be connected together by steel wire ties or other approved methods to achieve at least 20' length embedded in the concrete. This is then bonded to the Electrical Service with a minimum of #4 AWG copper wire.

The re-bar can be stubbed up out of the footing/ foundation near where the electrical service or sub-panel will be installed **or** a ground wire attached directly to the re-bar in the concrete with an approved clamp prior to pouring concrete. The re-bar stub does not need to extend above a basement floor if connectors approved for direct burial are used to connect the ground wire. The re-bar cannot extend through or terminate in fill, dirt, clay, gravel, etc.

This would also apply to outbuildings, sheds & garages where reinforcing bar is used in the footing, thickened perimeter slab or foundation and that will have a 30A or greater service or feeder. This would not apply to an outbuilding that is fed by only a 15A or 20A single or multi-wire branch circuit per Nec 250.32.

If a Concrete-Encased Electrode (Ufer Ground) is installed and bonded per Nec 250.52(3), no other electrodes (ground rods) are required. The Concrete-Encased Electrode may be the single Grounding Electrode. Metal water service lateral, metal water and gas piping shall be bonded per code. **Does not apply to epoxy coated steel or fiberglass re-bar.

***Does not apply to epoxy coated steel or fiberglass re-bar.*